HUAYU

Operating Instruction

Universal → Remote →

■ HR-330E

Universal Remote


Thank you to use this remote control, after will read please retainsthis instruction booklet, in order to will establish in the futuretime will use!

About this Remote controller

HR-330E is our latest unviversal DVD remote. It can control hundred different type of DVD in the world. Its special automatic searching way makes you easy and convenient to use it.

HR-330E is your best choice for your original DVD remote lost, damaged.

Panel Description



Installing the batteries

Open the battery cover and pay attention to the +/- marks, insert two new AAA(size5)batteries(not supplied)



Note on batteries

Do not mix old batteries with new ones or mix different types of batteries together. If the electrolytes leaks inside the battery compartment, clean it with a piece of cloth and put in a new battery.

Setting up the DVD

There are three set up method (A,B,C) for this remote please choose any one of them

A.Entering the code

 Turn on your DVD, and looking for the correct code for your device from the component code numbers".



Press the "set" key continuously,until the light is on then release.



3.Enter the 3-digit code you have selected for you device, if the code you entered wasn't the figure or the hundred digit big than 3, the light will flash 3 times then you must reset. if you enter the 3 correct code the light will flash every time then the light will out.



4.Press "set" key you will back out or don't press any key just wait for 25 seconds you also can back out.



※ If cann't work then repeat step1。


A Maybe will have many code can suitable your DVD so we suggest you to test all of them and find the more exactly code for your DVD.

B.Manual function of search

 Turn on your DVD, then keep on press the "set" key (about 5 seconds) until the light is on.



2.Press "play" key confinuously then will enter the search code



During search code, press other key will send out the data.




4.Press "set" key you will back out or don't press any key just wait for 25 seconds you also can back out.



※ If cann't work then repeat step2...

C.Automatic function of search

 Turn on your DVD, then keep on press the "set" key (about 5 seconds) until the light is on.



2.Press the "power" key,



3.Press any key to stop, then press " set" key to preservation and back out.



4.Before press "power" key,don't press any key in 25 seconds can back out.

※ If cann't work then repeat step1.。

Trouble shooting

If you have problems in setting up or using the controller

- Check that you are aiming the controller directly at the SAT and that there are no obstructions between the controller and the SAT.
- Make sure the batteries you are using are not worn out, and that they are in serted correctly.
- Check that your SAT has receive capability. For example:if your SAT did not come with a remote controller it probably is not capable of being controlled by a remote controller.
- If you do not operate properly, the controller will close down. At this time you have to remove the batteries and wait for 20 minutes. Insert the batteries again and the controller recover again.

Specifications

Operable distance:More than 8 meters Power requirement:Two size AA batteries. Dimensions:45x135x22mm(w/h/d) Mass:approx.100g(not including batteries)

Service

If you have troubles in using the controller and the "Trouble shooting" can not help you.please contact us.We will do our best to service you. Please don't open the controller by yourself.We will not take the responsibility if you open it by yourself.



WWW.huayu.cc

This company reserves the right to interpretation of the User's Manual. Design and technical parameters may vary without notice.

